

Protocol

# CD62L Fab-TACS<sup>®</sup> Magnetic Microbead Starter Kit

Cat. no. 6-8000-104

human, for PBMCs

## 1. GENERAL INFORMATION & TECHNICAL SPECIFICATIONS

Kit components:

Cat. no.	Product	Quantity	Required/total cells		
			$1 \times 10^7$	$1 \times 10^8$	$1 \times 10^9$
6-5510-005	Strep-Tactin <sup>®</sup> Magnetic Microbeads, 75 $\mu$ l	1	15 $\mu$ l	150 $\mu$ l	1500 $\mu$ l
6-8005-150	CD62L Fab-Strep, human, lyophilized, 50 $\mu$ g	1	1 $\mu$ g	10 $\mu$ g	100 $\mu$ g
6-6996-001	100 mM Biotin stock solution, 250 $\mu$ l	1	100 $\mu$ l	200 $\mu$ l	600 $\mu$ l
6-6320-025	10x Buffer CI, 25 ml 10x PBS containing 10 mM EDTA and 5% BSA	1	3-4 ml	6-7 ml	18-19 ml

- Specifications:** For isolation **out of  $5 \times 10^7$**  peripheral blood mononuclear cells (PBMCs)
- Required:** ddH<sub>2</sub>O for Buffer CI dilution; StrepMan Magnet (Cat. no. 6-5650-065)
- Storage:** Store all components at 2 - 8 °C. Store reconstituted Fab-Strep at -80 °C. (Buffer CI may also be stored at 15 - 25 °C)
- Stability:** 6 months after shipping.
- Shipping:** Blue ice
- Warnings:** Products are not classified as hazardous according to (EC) No 1272/2008 [CLP]. A Material Safety Data Sheets are provided.

## 2. INITIAL PREPARATIONS

### 2.1. Reagent preparation

Volumes are suitable for isolating target cells out of **up to  $1 \times 10^7$**  PBMCs. For higher cell numbers, Fab-Strep and Strep-Tactin® Magnetic Microbead volumes should be upscaled linearly according to total cell numbers (e.g., for  $5 \times 10^7$  cells use 5x indicated Fab-Strep volume). Adapt other volumes according to **Table 1**.



**Cell labeling and isolation (3.1. and 3.2.) has to be performed at 4 °C.** Please make sure that all reagents and cells are accordingly refrigerated before starting the protocol. **The subsequent removal of reagents and washing (3.3 and 3.4) has to be performed at room temperature.**


**2.1.1** Prepare 1x Buffer CI by diluting stock with ddH<sub>2</sub>O.

**2.1.2. Optional:** Wash Strep-Tactin® Magnetic Microbeads before use to remove sodium azide. Add **1 ml** Buffer CI to required volume of microbeads (see 2.1.4.). Mix carefully and separate beads from buffer using a magnet. Discard supernatant and resuspend magnetic microbeads in Buffer CI (initial volume as in 2.1.4.).

**2.1.3.** Resuspend **50 µg** Fab-Strep in **1 ml** Buffer CI for a final concentration of **50 µg/ml**.



Store Fab-Strep solution in aliquots at **-80 °C** for up to **6 months**.



**2.1.4.** Mix **20 µl** (1 µg) Fab-Strep with **15 µl** Strep-Tactin® Magnetic Microbeads. Incubate under constant gentle agitation for **5 min** (up to 24 h) at **4 °C**.

**2.1.5.** Prepare 1 mM Biotin Elution Buffer by diluting **100 µl** of 100 mM Biotin stock solution in **10 ml** Buffer CI. Mix thoroughly. Keep at **room temperature**.

### 2.2. Sample preparation

Prepare  **$1 \times 10^7$**  PBMCs in **30 µl** Buffer CI. Buffer CI volume should be upscaled linearly for higher cell numbers (e.g., use 5x 30 µl Buffer CI for  $5 \times 10^7$  total cells). Cells should be cooled down to **4 °C** before starting the protocol.

**Table 1: Recommended volumes & tube sizes for different cell numbers**

Starting cell number	Recommended tube size [ml]	Resuspension volume [ml]	Total Biotin Elution Buffer [ml]	3.3.1. [ml]
$\leq 1 \times 10^7$	15	5	10	5
$\leq 1 \times 10^8$	15	10	20	10
$\leq 1 \times 10^9$	50	30	60	30

## 3. PROTOCOL

### 3.1. Cell labeling

Perform all steps at **4 °C**.




**3.1.1.** Add the pre-incubated Fab-Strep Microbead preparation (2.1.4.) to the cells and mix thoroughly by gentle pipetting.



**3.1.2.** Incubate for **10 min** under gentle constant agitation, e.g. on a roller mixer, to prevent cells from sedimentation. Continue with 3.2.1.

### 3.2. Magnetic cell isolation

Perform all steps at **4 °C**.



**3.2.1.** Add **5 ml** of Buffer CI to the cells. Mix thoroughly by gentle pipetting.



**3.2.2.** Incubate the tube on a magnet for **1 min**, remove entire supernatant carefully.



**3.2.3.** Repeat steps 3.2.1. and 3.2.2 twice. Continue with step 3.3.1.

### 3.3. Removal of magnetic microbeads

Perform all steps at **room temperature**.



**3.3.1.** Resuspend cells in **5 ml** Biotin Elution Buffer (2.1.5.). Mix by thoroughly by pipetting and incubate for **10 min** at **room temperature** on a roller mixer.



**3.3.2.** Incubate the tube on a magnet for **1 min**, collect entire supernatant carefully and transfer it to a new collection tube.



**3.3.3.** Repeat step 3.3.1. and 3.3.2. once.

**3.3.4.** Pool the supernatants and collect cells by centrifugation (**400 x g, 6 - 10 min**).


Remove supernatant and resuspend cells in appropriate buffer or medium for further applications.



If further removal of magnetic microbeads is needed (e.g. for further positive enrichment steps), proceed to step 3.4.

### 3.4. Removal of remaining magnetic microbeads

Perform all steps at **room temperature**.



**3.4.1.** Discard supernatant carefully. Resuspend cell pellet in **5 ml Buffer CI** and incubate for **5 min** under agitation (e.g. on a roller mixer) at **room temperature**.



**3.4.2.** Place tube back on the magnet (to remove any potential residual beads) and incubate for **3 min**.

**3.4.3.** After incubation, transfer supernatant to a **new tube** and centrifuge cells for **6 - 10 min at 400 x g**.

**3.4.4.** Remove supernatant and resuspend cells in appropriate buffer or medium for further applications.



To perform further positive isolation or depletion steps please start the protocol once more at **3.1**.

## 4. TROUBLESHOOTING

### Low yield

#### Option 1:

Titrate the ratio between Fab-Streps and Strep-Tactin® Magnetic Microbeads for different cell numbers.

#### Option 2:

Increase incubation time of cells with Fab-Strep-Microbead mix (3.1.2.).

#### Option 3:

Make sure that you carefully remove supernatants during incubation on the magnet (3.2.) without disrupting the binding of the microbeads to the magnet.

#### Option 4:

Check for biotin contamination in your samples.

### Low purity

Increase number of washing steps (3.2.)

### Microbead contamination

Make sure that you carefully remove supernatants during incubation on the magnet (3.3. and 3.4.) without disrupting the binding of the microbeads to the magnet.


### High amount of cell death

Make sure that you always work at the recommended temperatures.


## 5. EXAMPLE DATA

Isolation of CD62L<sup>+</sup> cells from T cell pre-enriched cells using the CD62L Fab-TACS® Magnetic Microbead Starter Kit. Unlysed cells were stained with CD62L-PE (DREG-56) / CD8-PE-Cy7 (HIT8a) and analyzed by flow cytometry (CyAn ADP, BC). Dead cells were excluded from the analysis using PI staining. Doublet and debris discrimination were performed using different FSC/SSC signals.

### Before isolation



### After isolation





Check our Downloads page

[www.iba-lifesciences.com/download-area.html](http://www.iba-lifesciences.com/download-area.html)

for the latest version of this manual.



Info on warranty / licensing and trademarks available at:

[www.iba-lifesciences.com/patents-licenses-trademarks.html](http://www.iba-lifesciences.com/patents-licenses-trademarks.html)



If you have any questions, please contact

[fab-tacs@iba-lifesciences.com](mailto:fab-tacs@iba-lifesciences.com)

We are here to help!

